

Sequence 5030 JOY STICK REVERSE FAST

JOY STICK REVERSE
FAST A/B GATEWAY
JST_REV_FAST

JOY STICK REVERSE
SLOW A/B GATEWAY
JST_REV_SLOW

JOY STICK FORWARD
SLOW A/B GATEWAY
JST_FWD_SLOW

JOY STICK FORWARD
FAST A/B GATEWAY
JST_FWD_FAST

34

JOY STICK REVERSE
FAST

tb_rev_fast

Sequence 6000 THR BUGGY FAST REF ENABLE

JOY STICK FORWARD
FAST

tb_fwd_fast

JOY STICK FORWARD
SLOW

tb_fwd_slow

JOY STICK REVERSE
SLOW

tb_rev_slow

35

JOY STICK REVERSE
FAST

tb_rev_fast

THR BUGGY FAST REF
ENABLE

TB_FAST

Sequence 6500 THR BUGGY FWD IN REFERENCE ENABLE

JOY STICK FORWARD
SLOW

tb_fwd_slow

JOY STICK REVERSE
SLOW

tb_rev_slow

JOY STICK REVERSE
FAST

tb_rev_fast

36

JOY STICK FORWARD
FAST

tb_fwd_fast

THR BUGGY FWD IN
REFERENCE ENABLE

TB_FWD_IN

Sequence 7000 THR BUGGY RUN P/B

37

up trans
tb_fwd_slow_ut

THR BUGGY RUN
P/B enable
TB_RUN_PB_en

up trans
tb_fwd_fast_ut

up trans
tb_rev_slow_ut

up trans
tb_rev_fast_ut

38

THR BUGGY RUN
P/B enable
TB_RUN_PB_en

THR BUGGY RUN
P/B timer

TOF
Timer Off Delay
Timer TB_RUN_PB_tmr
Preset 1000
Accum 0

EN
DN

39

THR BUGGY RUN
P/B timer
TB_RUN_PB_tmr.EN

THR BUGGY RUN
P/B
TB_RUN_PB

THR BUGGY RUN
P/B timer
TB_RUN_PB_tmr.TT

Sequence 8000 THR BUGGY STOP P/B

40

THR BUGGY IN
POSITION LATCH
TB_IN_POS

THR BUGGY STOP
P/B
tb_stop_pb

Sequence 8100 THR BUGGY STOP CONTROLER CENTERED

41


JOY STICK FORWARD
SLOW
tb_fwd_slow


JOY STICK FORWARD
FAST
tb_fwd_fast


JOY STICK REVERSE
SLOW
tb_rev_slow


JOY STICK REVERSE
FAST
tb_rev_fast


THR BUGGY STOP
CONTROLER CENTERED
cont_center






















Sequence 32767 SOFTWARE E-STOP RELAY

92

TB_FLT_TAC

TB_FLT_OSP

THR BUGGY EMERGENCY
STOP INTRLCK #1

tb_esr_i1

AMX RACK CLOKED
CARDS OK

RACK_CARD_FLT

SOFTWARE E-STOP
RELAY

SOFT_ESTOP

(End)

	A	B	C	D	E	F	G	H	
1									
2									
3									
4									
5									
6									

